

# Gemini Duets Laser Settings Guide



While every laser is different, here are recommended laser settings to try out using the Duets. We recommend these settings to be adjusted for best results.

## 35 Watt Systems

### **Laser Indoor/Laser XT:**

Raster power: 40  
Raster speed: 100  
Vector power: 45  
Vector speed: 20

### **DuetsContours:**

Raster power: 35  
Raster speed: 100  
Vector power: 30  
Vector speed: 20

### **Duets ADA Tactiles:**

1/32" Vector power: 30  
1/32" Vector speed: 20  
1/16" Vector power: 100  
1/16" Vector speed: 7  
1/8" Vector power: 100  
1/8" Vector speed: 10

## 50 Watt Systems

### **Laser Indoor/Laser XT:**

Raster power: 30  
Raster speed: 100  
Vector power: 35  
Vector speed: 20

### **DuetsContours:**

Raster power: 25  
Raster speed: 100  
Vector power: 22  
Vector speed: 20

### **Duets ADA Tactiles:**

1/32" Vector power: 22  
1/32" Vector speed: 20  
1/16" Vector power: 100  
1/16" Vector speed: 16  
1/8" Vector power: 100  
1/8" Vector speed: 20



To place an order please give us a call at 1-800-866-7121 or visit our website at [www.bfplasticsinc.com](http://www.bfplasticsinc.com)

